COURSE NAME: ANNEX 14



HOMAviation Training Center مرکز آموزش هـای هواییهمـــا



**Amir Ahmad Toopchi** 

Annex 14 to the Convention on International Civil Aviation

Aerodromes

Volume I

Aerodrome Design and Operations

Ninth Edition, July 2022



Aerodromes

Volume II

Heliports

Fifth Edition, July 2020










## who is this course for?















## Why attended? What is it for me?





Familiar with ICAO ANNEX14 and their objective

Familiar with AERODROME and it structure


Importance rules of design aerodrome in aviation





## Module objective

This module learns to us about aerodrome and runway characteristic's in civil aviation and gets good foundation of definitions that used in aerodromes.







## Lesson plan


Upon completion of this module learners will be able to:

1- Explain definitions related to aerodrome, runway, runway conditions, PCR, ACR and other shapes and sings and marking in aerodrome

2- define clearway, STOPWAY, TORA, TODA, LDA, ASDA, and explain color in sings and lights in aerodrome surface













**Aerodrome.** A defined area on land or water (including any buildings, installations and equipment) intended to be used either wholly or in part for the arrival, departure and surface movement of aircraft.

'Airfield': a defined area of grass on which runways may be marked out or the direction of landing is indicated (an airfield is exactly that: a field (usually unprepared) which is occasionally used as a landing ground for aeroplanes).

'Airport': a point of entry or exit from a country by air, that may have several defined paved runways.

The accepted and legally correct term is an aerodrome.



























## Runway

A defined **rectangular** area on a **land** aerodrome prepared for the landing and take-off of aircraft.









Threshold. The beginning of that portion of the runway usable for landing.

**Touchdown zone.** The portion of a runway, beyond the threshold, where it is intended landing aeroplanes first *contact the runway*.

**Touchdown.** The point where the nominal glide path intercepts the runway.

Note.— "Touchdown" as defined above is only a datum and is not necessarily the actual point at which the aircraft will touch the runway. (Doc4444)







- Aerodrome elevation. The elevation of the highest point of the landing area.
- Landing area. That part of a movement area intended for the landing or take-off of aircraft.

Movement area. That part of an aerodrome to be used for the take-off, landing and taxiing of aircraft, including aprons.


Manoeuvring area. That part of an <u>aerodrome</u> to be used for the take-off, landing and <u>taxiing</u> of aircraft, excluding <u>aprons</u>.







• Aerodrome elevation. The elevation of the highest point of the landing area.








### HOMAviation Training Center مرکز آموزش های هوایی هم






Aerodrome reference point. The designated geographical location of an aerodrome.





• The aerodrome reference point (ARP) provides the aerodrome's position in terms of coordinates; its geographic position in longitude and latitude. These coordinates are provided in degrees, minutes, and seconds, and they form the basis for the aerodrome's position published on maps and charts.





Aeronautical ground light. Any light specially provided as an aid to air navigation, other than a light displayed on an aircraft.





Aerodrome beacon. Aeronautical beacon used to indicate the location of an aerodrome from the air.








### Location

5.3.3.4 The aerodrome beacon shall be located **on or adjacent** to the aerodrome in an area of low ambient background lighting.











Where used, the coloured flashes emitted by beacons at land aerodromes shall be green, and coloured flashes emitted by beacons at water aerodromes shall be yellow.



Land aerodrome




Water aerodrome




In the case of a **combined water and land aerodrome**, coloured flashes, if used, shall have the colour characteristics of whichever section of the aerodrome is designated as the principal facility.


Aeronautical beacon used to indicate the location of an aerodrome from the air.




Land aerodrome



Water aerodrome



Heliport




Military aerodrome



Barrette. Three or more aeronautical ground lights closely spaced in a transverse line so that from a distance they appear as a short bar of light.







**Apron**. A defined area, on a land aerodrome, intended to accommodate aircraft for purposes of loading or unloading passengers, mail or cargo, fuelling,

parking or maintenance.









# Pavement classification number (PCN). A number expressing the bearing strength of a pavement for unrestricted operations.

It means that no special permission is required prior to each operation.







## Applicable as of 28 November 2024

Pavement classification rating (PCR). A number expressing the bearing strength of a pavement.

Aircraft classification rating (ACR). A number expressing the relative effect of an aircraft on a pavement for a specified standard subgrade category.

2.6.3 The PCR reported shall indicate that aircraft with an aircraft classification rating (ACR) equal to or less than the reported PCR may operate on the pavement subject to any limitation on the tire pressure or aircraft all-up mass for specified aircraft type(s).

The Current software ICAO-ACNw1.0 will be replaced by ICAO ACR1.0 (already developed) to compute every aircraft ACRs at any weight and center of gravity position.



OIII 29L 90 /F

**/A** 

**/X** 

**HOMA**viation Training Center مرکز آموزش هـای هوایی هم

Example: OIII 29R 72 /R

/ W / **A** 

/ **T** 

**/T** 

### **Pavement Type**

### F - Flexible



**Subgrade Strength** 

A - High

B - Medium

C - Low

D - Ultralow

**Tire Pressure** 

W - Unlimited


X - High (254 psi)

Y - Medium (181 psi)

Z - Low (73 psi)



R - Rigid



### **ACN at Maximum Taxi Weight**

@787guide


**Evaluation Method** 

**U** - Aircraft Experience


T - Technical

AIRCRAFT TYPE	MAXIMUM TAXI WEIGHT	TIRE PRESSURE	ACN FOR RIGID PAVEMENT SUBGRADES				ACN FOR FLEXIBLE PAVEMENT SUBGRADES			
			A	В	С	D	А	В	С	D
787-8	228 383 kg (503 500 lbs)	228 psi	61	71	84	96	60	66	81	106
787-9	254 692 kg (561 500 lbs)	226 psi	65	76	90	104	66	73	88	118
787-10	254 692 kg (561 500 lbs)	226 psi	66	77	91	105	67	74	89	119


















PCN value (max 200) PCN pavement subgrade

A [high] - D [ultra low] z.b. B [medium strength subgrade.]

PCN evaluation method

T [Technical evaluation.] or U [using aircraft experience.]

80/R/B/X/T

PCN pavement type R [Rigid] or F [Flexible] PCN max tire pressure code

W [high] – Z [very low] z.b. X [Medium: pressure limited to 1.50 MPa (217 psi)]



Example: A B722 with 78500kg on a rigid pavement, medium strength subgrade, tire pressure of 1.15 Mpa the ACN is calculated to be 48. (Doc 9157, Part3, 1.1.3.10)

Aircraft classification number (ACN). A number expressing the relative effect of an aircraft on a pavement for a specified standard subgrade category.

Note.— The aircraft classification number is calculated with respect to the centre of gravity (CG) position which yields the critical loading on the critical gear. Normally the aft most CG position appropriate to the maximum gross apron (ramp) mass is used to calculate the ACN. In exceptional cases the forwardmost CG position may result in the nose gear loading being more critical.

## AERODROME DESIGN MANUAL




PART 3

**PAVEMENTS** 

SECOND EDITION — 1983









### Example 2:

An AIP contains the following information related to a runway pavement:

PCN of the pavement = 80

Pavement type = rigid

Subgrade category = medium strength

Tire pressure limitation = none

Determine whether the pavement can accept the following aircraft at the indicated operating masses and tire pressures:

		Mass	Tire pressure			
Airbus A 300 Model B2	at	142 000 kg	1.23 MPa			
B747-100	at	334 751 kg	1.55 MPa			
Concorde	at	185 066 kg	1.26 MPa			
DC-10-40	at	253 105 kg	1.17 MPa			

## Solution:

ACNs of these aircraft from Appendix 5 of this Manual are 44, 51, 71 and 53, respectively. Since the pavement in question has a PCN of 80 it can accept all of these aircraft.



			Tire		ACN	FOR		ACN FOR FLEXIBLE PAVEMENT SUBGRADES - CBR				
				RIGID PA	AVEMENT SUI	KGRADES -	· MN/m <sup>3</sup>					
Aircraft	All-up	Load on					Ultra-					
type mass one main pressure gear leg	High 150	Medium 80	Low 40	10w 20	High 15	Medium 10	Low 6	Very low 3				
	(kg)	(%)	(MPa)					·				
1	2	3	4	5	6	7	8	9	. 10	11	12	
A300 B2	137 000	47.0	1.2	35	42	50	58	39	43	53	68	
Airbus	85 910	MACHINE.		18	21	25	29	20	22	24	34	
A300 B2	142 000	47.0	1.29	35	45	53	61	40	45	55	71	
Airbus	85 910			19	22	26	30	21	22	25	34	
A300 B4	150 000	47.0	1.39	41	49	57	65	43	49	59	76	
Airbus	88 180			20	22	26	31	21	22	25	35	
A300 B4	157 000	47.0	1.48	45	53	62	70	46	52	63	80	
Airbus	88 330			20	22	26	31	21	22	25	36	
A300 B4	165 000	47.0	1.29	46	55	64	73	49	56	68	84	
Airbus	88 505			17	20	25	29	20	21	25	36	

(Doc 9157, Part3, Appendix 5)



#### JEPPESEN

#### **AIRPORT DATA - GENERAL**

1547

#### **ACN TABLES**

Aircraft Type	All-up Mass <sup>1</sup> (Maximum Apron Mass) (Operating Mass Empty)		Load on one main gear leg (%)	Standard Aircraft Tire Pressure			ACN relative to								
							Rigid Pavement Subgrades				Flexible Pavement Subgrades				
							= 150 ui MN/m <sup>3</sup> =	Medi- Low um K K = = 80 40 MN/m <sup>3</sup> MN/ m <sup>3</sup>	40 MN/	Ultra- low K = 20 MN/m	High CBR = 15%	Medi- um CBR = 10%	Low CBR = 6%	Very low CBR = 3%	
	lbs	kgs		psi	kg/c m <sup>2</sup>	mPa	Α	В	С	D	Α	В	С	D	
1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	
Airbus A300- B2	304014 192371	13790 0 87259	47.0	174	12.2	1.20	34 19	41 22	49 26	57 31	35 20	39 21	47 24	62 32	
Airbus A300- B2	315037	14290	47.0	186	13.1	1.28	37	44	53	60	37	41	50	65	
D2	193676	87851					20	23	27	31	20	22	25	33	
Airbus A300-	332674	15090	47.0	203	14.3	1.40	41	49	58	66	41	45	54	70	
B4	202858	0 92016					22	25	29	34	22	23	26	35	

**The California Bearing Ratio** (CBR) is a measure of the strength of the subgrade of a road or other paved area, and of the materials used in its construction. The ratio is measured using a standardized penetration test first developed by the **California Division of Highways for highway** engineering











- 6- What shall be the color of aerodrome beacon signal alternating with white flashes at land aerodrome?
- A) Yellow.
- B) Green.
- C) Red.
- D) None.


- 16- What shall be the frequency of total flashes per minute of aerodrome beacon?
- A) 10-20
- B) 10-30
- C) 20-30
- D) 20-40



6- What shall be the color of aerodrome beacon signal alternating with white flashes at land aerodrome?

- A) Yellow.
- B) Green.
- C) Red.
- D) None.






16- What shall be the frequency of total flashes per minute of aerodrome beacon?


- A) 10-20
- B) 10-30
- C) 20-30
- D) 20-40







Hot spot. A location on an aerodrome movement area with a history or potential risk of collision or runway incursion, and where heightened attention by pilots/drivers is necessary.





Aircraft stand. A designated area on an apron intended to be used for parking an aircraft.

AIP
ISLAMIC REPUBLIC OF IRAN

Tehran / Imam Khomaini INTL

AD 2-5 OHE WEF 5 DEC 19

#### IKA AIRCRAFT DOCKING GUIDANCE SYSTEM -SAFEDOCK

#### 1. INTRODUCTION

1.1 The Aircraft Docking Guidance System is a fully automatic aircraft docking guidance system installed at the fixed gates in Terminal of Imam Khomaini INTL Airport.






Figure 2
Aircraft tracked and identified correctly.

#### 2. DESCRIPTION OF SYSTEM

2.1 The system is based on a laser scanning technique and



### HOMAviation Training Center مرکز آموزش هـای هوایی همـــا





**Clearway.** A defined rectangular area on the **ground or water** under the control of the appropriate authority, selected or prepared as a suitable area over which an aeroplane may make a portion of its **initial climb to a specified height**.






- 3.6.1 **Recommendation**. The origin of a clearway should be at the end of the TORA.
- 3.6.2 **Recommendation**. The **length** of a clearway should not exceed **half the length** of the TORA.
- 3.6.3 **Recommendation**.— A clearway should extend **laterally** to a distance of at east 75 m on each side of the extended centre line of the runway.

3.6.4 **Recommendation**.— The ground in a clearway should not project above a plane having an upward slope of 1.25 per cent.





**Stopway.** A defined rectangular area on the **ground** at the end of take-off run available prepared as a suitable area in which an aircraft can be stopped in the case of an abandoned take-off.








The area provided to reduce the erosive effects of jet blast and propeller wash may be referred to as a blast pad












## Arresting system. A system designed to decelerate an aeroplane overrunning the runway.












3.7.1 A stopway **shall** have the **same width as the runway** with which it is associated.

3.7.4 The surface of a paved stopway <u>shall</u> be so constructed or resurfaced as to provide surface <u>friction</u> characteristics at or above those of the associated runway.






## 5.3.16 Stopway lights

5.3.16.1 Stopway lights shall be provided for a stopway intended for use at night.


5.3.16.2 Stopway lights shall be placed along the **full length of the stopway** and shall be in **two parallel rows** that are equidistant from the centre line and coincident with the rows of the runway edge lights. Stopway lights shall also be provided **across the end of a stopway** on a line at right angles to the stopway axis as near to the end of the stopway as possible and, in

any case, not more than 3 m outside the end.












# Runway threshold lights





# 5.3.16.3 Stopway lights shall be fixed unidirectional lights showing red in the direction of the runway.











Runway strip. A defined area including the runway and stopway, if provided, intended:a) to reduce the risk of damage to aircraft running off a runway; and

b) to protect aircraft flying over it during take-off or landing operations.





## Runway end safety area (RESA).


An area symmetrical about the extended runway centere line and adjacent to the end of the strip primarily intended to reduce the risk of damage to an aeroplane undershooting or overrunning the runway.

The runway-end safety area must extend at least 90 meters for all instrument runways (codes 1 to 4) and must be at least twice the width of the runway.





Balked landing. A landing manoeuvre that is unexpectedly discontinued at any point below the obstacle clearance altitude/height (OCA/H).





## 44- A lighted heliport may be identified by a:

- A) Green, yellow, and white rotating beacon.
- B) Flashing yellow light.
- C) Blue lighted square landing area.
- D) Two quick white flashes between green flashes.


## 34- The color of the fixed, unidirectional runway threshold and wing bar lights shall

- A) Yellow
- B) White
- C) Green
- D) Blue



## 44- A lighted heliport may be identified by a:


- A) Green, yellow, and white rotating beacon.
- B) Flashing yellow light.
- C) Blue lighted square landing area.
- D) Two quick white flashes between green flashes.



Heliport

## 34- The color of the fixed, unidirectional runway threshold and wing bar lights shall

- A) Yellow
- B) White
- C) Green
- D) Blue






- Declared distances are needed for aircraft performance calculations. They
  are used to calculate if a runway can safely be used for takeoffs and landings.
- a) Take-off run available (TORA). The length of runway declared available and suitable for the *ground run of an aeroplane taking off*.






• b) Take-off distance available (TODA). The length of the take-off run available plus the length of the clearway, if provided.







c) Accelerate-stop distance available (ASDA). The length of the take-off run available olus the length of the stopway, if provided.







• d) Landing distance available (LDA). The length of runway which is declared available and suitable for the ground run of an aeroplane landing.














Takeoff can be aborted in the event of an engine failure (V1)

In the event of aborted takeoff, No Stopway required if Aircraft can Stop using remaining runway pavement STOPWAY provided if extra pavement is required for stopping




Accelerate-Stop distance (With or without Stopway)




### Displaced threshold. A threshold not located at the extremity of a runway.














Pre-threshold area usable for take-off or stopway threshold. Threshold temporarily displaced for 6 months or less Pre-threshold area un-usable for aircraft movements

Pre-threshold area fit for use as stopway but not for normal movement of aircraft

Note: If there are 4 parallel runways, the numbers are changed e.g. 26L; 26R; 27L; 27R




## 5.2.2 Runway designation marking

5.2.2.1 A runway designation marking shall be provided at the **thresholds** of a paved runway.


[NOT INSTRUMENT

5.2.2.4 A runway designation marking shall consist of a two-digit number and on parallel runways shall be supplemented with a letter. The two-digit number shall be the whole number nearest the one-tenth of the magnetic North when viewed from the direction of approach.





- 5.2.2.5 In the case of parallel runways, each runway designation number shall be supplemented by a letter as follows, in the order shown from left to right when viewed from the direction of approach:
- for two parallel runways: "L" "R";
- for three parallel runways: "L" "C" "R";
- for four parallel runways: "L" "R" "L" "R";
- for five parallel runways: "L" "C" "R" "L" "R" or "L" "R" "L" "C" "R"; and
- for six parallel runways: "L" "C" "R" "L" "C" "R".
- 5.2.1.4 Runway markings shall be white.
- 5.2.1.5 Taxiway markings, runway turn pad markings and aircraft stand markings shall be yellow.



Example: 29L, 29C, 29R













Six Parallel Runways



Foreign object debris (FOD). An inanimate object within the movement area which has no operational or aeronautical function and which has the potential to be a hazard to aircraft operations.

Holding bay. A defined area where aircraft can be held, or bypassed, to facilitate efficient surface movement of aircraft.







# Holding bay









Taxiway markings are YELLOW



Runway turn pad. A defined area on a *land* aerodrome adjacent to a runway for the purpose of completing a 180-degree turn on a runway.









LFOB - Runway turn pad
Threeshold 30 THR 30 turn pad (night) inway turn pad THR 30 TWY R exit (night)

No centerline lighting

Google earth



### 5.1.1 Wind direction indicator (windsock)

- 5.1.1.1 An aerodrome shall be equipped with at least one wind direction indicator.
- 5.1.1.2 A wind direction indicator shall be located so as to be **visible** from aircraft in **flight** or on the **movement** area.
- 5.1.1.3 The colour or colours should be so selected as to make the wind direction indicator clearly visible and understandable from a height of at least 300 m, having regard to background.






## 5.1.1 Wind direction indicator (windsock)


Preferably white or orange. Where a combination of two colors is required to give adequate conspicuity against changing backgrounds, they should preferably be orange and white, red and white, or black and white, and should be arranged in five alternate bands, the first and last bands being the darker colour.

The wind direction indicator should be in the form of a truncated cone made of fabric and should have a length of not less than 3.6 m and a diameter, at the larger end, of not less than 0.9 m.










**6.92 Wind Sleeve.** A wind sleeve (windsock) indicates the wind direction and speed. (Large = 40 kt; medium = 30 kt; small = 20 kt) Max wind speed (i.e. 40 kt) Half wind speed (i.e. 20 kt) Calm



Wind tees and tetrahedrons can swing freely, and will align themselves with the wind direction.

The wind tee and tetrahedron can also be manually set to align with the runway in use, therefore a pilot should also look at the wind sock if available.



### Obstacle

Obstacle. All fixed (whether temporary or permanent) and mobile objects, or parts thereof, that:

- a) are located on an area intended for the surface movement of aircraft; or
- b) extend above a defined surface intended to **protect aircraft in flight**; or
- c) stand outside those defined surfaces and that have been assessed as being a hazard to air navigation.





#### 11- From what height, the wind direction indicator shall be visible?


- A) 200 m
- B) 300 m
- C) At least 300 m
- D) All answers are correct



#### 11- From what height, the wind direction indicator shall be visible?

- A) 200 m
- B) 300 m
- C) At least 300 m
- D) All answers are correct


5.1.1.3 The colour or colours should be so selected as to make the wind direction indicator clearly visible and understandable from a height of at least 300 m, having regard to background.





#### 12- The runway designated number shall be provided from?

- A) Magnetic (N)
- B) True (N)
- C) Grid (N)
- D) Compass (N)



- A) A landing aircraft can be stopped only in emergency.
- B) A landing aircraft can be stopped if overcoming the end of runway.
- C) An aircraft can be stopped in the case of an abandoned takeoff.
- D) An aircraft taking-off or landing can be stopped.



# 25- Which of the following group shows the correct designators for three parallel runways seen from the direction of the approach?


- A) 29, 29C, 29.
- B) 29R, 29C, 29L.
- C) 29L, 29, 29R.
- D) 29L, 29C, 29R.





# 25- Which of the following group shows the correct designators for three parallel runways seen from the direction of the approach?

- A) 29, 29C, 29.
- B) 29R, 29C, 29L.
- C) 29L, 29, 29R.
- D) 29L, 29C, 29R.





#### 28- Taxiway markings and aircraft stand markings are:

- A) White.
- B) Grey.
- C) Yellow.
- D) Red.



- A) Movement area.
- B) Taxiway.
- C) Clearway.
- D) Runway.



#### 28- Taxiway markings and aircraft stand markings are:

- A) White.
- B) Grey.
- C) Yellow.
- D) Red.



#### 27- When taxiing on a surface with white markings, you are rolling on a:

- A) Movement area.
- B) Taxiway.
- C) Clearway.
- D) Runway.








### Module objective

This module learns us about type of runway, length, width, and marker in civil aviation and gets good foundation of definitions that used for identification a runway





## Aeroplane reference field length

The minimum field length required for take-off at maximum certificated take-off mass, sea level, standard atmospheric conditions, still air and zero runway slope, as shown in the appropriate *aeroplane flight manual* prescribed by the certificating authority or equivalent data from the aeroplane *manufacturer*.

- Field length means balanced field length for aeroplanes, if applicable, or take-off distance in other cases.
- The balanced field length is the shortest field length at which a balanced field takeoff can be performed.
- A balanced field takeoff is a condition where the accelerate-stop distance required (ASDR) is equal to the takeoff distance required (TODR).

### Aeroplane reference field length must be corrected as follows:

- 1) 7% for each 300m AMSL, then
- 2) 1% for each 1° Above 15°C, then
- 3) 10% for each 1% of slope.



### Aerodrome Reference Code

	CODE ELEMENT 1				CODE ELEMENT 2					
	Code number		Aeroplane reference field length	Code letter			Wing span	Outer main gear wheel span <sup>a</sup>		
	(1)		(2)	(3)			(4)	(5)		
	1		Less than 800 m	111111	Α		Up to but not including 15 m	Up to but not including 4.5 m		
	2	2	800 m up to but not including 1 200 m		В		15 m up to but not including 24 m	4.5 m up to but not including 6 m		
	3	3	1 200 m up to but not including 1 800 m		С		24 m up to but not including 36 m	6 m up to but not including 9 m		
	4		1 800 m and over		D		36 m up to but not including 52 m	9 m up to but not including 14 m		
AID AD OIV	(X, 2.12 , OIMM:				Е		52 m up to but not including 65 m	9 m up to but not including 14 m		
OIII, OIIE, OISS,			4E		F		65 m up to but not including 80 m	14 m up to but not including 16 m		
	I									

Doc 9157 part 1

a. Distance between the outside edges of the main gear wheels.



### Aerodrome Reference Code

Element 1 is a number based on the:

 aeroplane reference field length and


element 2 is a letter based on the aeroplane:

- wing span and
- the outer main gear wheel span.

AEROPLANE TYPE	REF CODE	ARFL (m)	Wingspan (m)	OMGWS (m)	
Lear Jet 55	3A	1292	13.4	2.5 5.8 7.9	
Fokker F28-2000	3B	1646	23.6		
Fokker:F27-500	3C	1670	29.0		
Airbus A300 B2	3D	1676	44.8	10.9	
Boeing: B737-200 B737-300 B737-400	4C 4C 4C	2295 2749 2499	28.4 28.9 28.9	6.4 6.4 6.4	
Boeing: B707-300 B757-200 B767-200ER	4D 4D 4D	3088 2057 2743	44.4 38.0 47.6	7.9 8.7 10.8	
Boeing: B747-300 B747-400 B777-200	4E 4E 4E	3292 3383 2500	59.6 64.9 60.9	12.4 12.4 12.8	



Outer main gear wheel span (OMGWS). The distance between the *outside edges* of the main gear wheels.





Marker. An object displayed above ground level in order to indicate an obstacle or delineate a boundary.

Marking. A symbol or group of symbols displayed on the surface of the movement area in order to convey aeronautical information.

#### Sign.

a) Fixed message sign. A sign presenting only one message. b) Variable message sign. A sign capable of presenting several predetermined messages or no

message, as applicable.







\*\*\*\*





Non-instrument runway. A runway intended for the operation of aircraft using visual approach procedures or an instrument approach procedure to a point beyond which the approach may continue in visual meteorological conditions.

19.31 Visual Runway. A non-instrument (visual) runway is used where take-off and landing criteria are determined visually. The criteria are usually defined by reference to ground visibility or RVR, cloud ceiling and day/night considerations.



## Instrument runway. One of the following types of runways intended for the operation of aircraft using instrument approach procedures:

- a) Non-precision approach runway. A runway served by visual aids and non-visual aid(s) intended for landing operations following an instrument approach operation type A and a visibility not less than 1 000 m.
- Precision approach runway, category I. A runway served by visual aids and non-visual aid(s) intended for landing operations following an instrument approach operation type B with a decision height (DH) not lower than 60 m (200 ft) and either a visibility not less than 800 m or a RVR not less than 550 m.
- Precision approach runway, category II. A runway served by visual aids and non-visual aid(s) intended for landing operations following an instrument approach operation type B with a decision height (DH) lower than 60 m (200 ft) but not lower than 30 m (100 ft) and a RVR not less than 30 m.
- d) Precision approach runway, category III. A runway served by visual aids and non-visual aid(s) intended for landing operations following an instrument approach operation type B to and along the surface of the runway and:
- A intended for operations with a decision height (DH) lower than 30 m (100 ft), or no decision height and a RVR not less than 175 m.
- B— intended for operations with a decision height (DH) lower than 15 m (50 ft), or no decision height and a RVR less than 175 m but not less than 50 m.
- C intended for operations with **no** decision height (**DH**) and **no RVR** limitations.



### Annex 6 Amend 44, 5/11/2020


a) Type A: a <u>MDH</u> or <u>DH</u> at or above 75 m (250 ft); and


b) Type B: a DH below 75 m (250 ft).

Type B instrument approach operations are categorized as:


- 1) Category I (CAT I): a DH not lower than 60 m (200 ft) and with either a <u>visibility</u> not less than 800 m or a RVR not less than 550 m;
- 2) Category II (CAT II): a DH lower than 60 m (200 ft) but not lower than 30 m (100 ft) and a RVR not less than 300 m; and
- 3) Category III (CAT III): a DH lower than 30 m (100 ft) or no DH and a RVR less than 300 m or no RVR limitations.








b) Non Precision Approach Runways, Visual Runways of LDA >1200m and where Threshold requires emphasis



#### c) Precision Approach Runways



Edge Marking





#### **Application**

5.2.3.1 A runway centre line marking shall be provided on a paved runway. [NOT INSTRUMENT]

#### **Characteristics**

5.2.3.3 A runway centre line marking shall consist of a line of uniformly spaced stripes and gaps

The length of a stripe plus a gap shall be not less than 50 m or more than 75 m.

The length of each stripe shall be at least equal to the length of the gap or 30 m, whichever is greater.

**HOMA**viation Training Center Precision مرکز آموزش هـای هوایی هم approach category I and non-precision approach runways 0.45 m mnm Non-precision Precision approach approach category
II and III runways 30 m 0.45 m mnm runways 20 m Non-instrument 0.9 m mnm 50 m mnm runways 20 m 0.3 m mnm 20 m 0 50 m mnm 30 m 30 m 30 m A 12 m 9 m mnm 12 m 6 m mnm 9 m 30 m 9 m mnm 22.5 m 12 m 12 m 30 m 30 m mnm 30 m  $\alpha = 1.8 \text{ m}$ 6 m α→II← →I≾H-α→II← 6 m‡mnm 6 mtmnm α → | ← → | ← α → | ←  $\rightarrow \mid \leftarrow \alpha$ aprx.

B - Parallel runways

A - General and all precision

approach runways

C - Optional pattern



### 5.2.4 Threshold marking

5.2.4.5 A runway threshold marking shall consist of a pattern of longitudinal stripes of uniform dimensions disposed symmetrically about the centre line of a runway for a runway width of 45 m.

The number of stripes shall be in accordance with the runway width as follows:

Runway width	Number of stripes	Stripe length			
18 meters	4	24 meters			
23 meters	6	24 meters			
30 meters	8	30 meters —	->	-	
45 meters	12	30 meters			
60 meters	16	30 meters			



approach runways


- 5.2.4.1 A threshold marking shall be provided at the threshold of a
- 1) paved instrument runway, and
- 2) of a paved non-instrument runway where the code number is 3 or 4 and the runway is intended for use by international commercial air transport.
- 5.2.4.4 The stripes of the threshold marking shall commence 6 m from the threshold.

	Code element 1
Code number	Aeroplane reference field length
1	Less than 800 m
2	800 m up to but not including 1 200 m
3	1 200 m up to but not including 1 800 m
4	1 800 m and over
12 m E E E E E E E E E E E E E E E E E E	12 m 22.5 m 22.5 m
α	$\alpha \rightarrow H \leftarrow \rightarrow H \leftarrow \alpha \rightarrow H \leftarrow 6 \text{ mmnm} \qquad 6 \text{ mmnm} \qquad \rightarrow H \leftarrow \alpha \qquad \alpha \rightarrow H \leftarrow \text{aprx.}$ $B - \text{Parallel runways} \qquad \qquad C - \text{Optional pattern}$

The stripes shall be continued across the runway. The stripes shall be at least 30 m long and approximately 1.80 m wide with spacings of approximately 1.80 m between



20.16 Transverse Stripe. Where a threshold is displaced from the extremity of a runway (the end of the concrete) or where the end is not at right angles to the runway centre line, a transverse stripe should be added to the threshold marking.





### 5.2.5 Aiming point marking

### **Application**

5.2.5.1 An aiming point marking shall be provided at each approach end of a paved instrument runway where the code number is 2, 3 or 4.

	Landing distance available					
Location and dimensions (1)	Less than 800 m (2)	800 m up to but not including 1 200 m (3)	1 200 m up to but not including 2 400 m (4)	2 400 m and above (5)		
Distance from threshold to beginning of marking	150 m	250 m	300 m	400 m		
Length of stripe <sup>a</sup>	30–45 m	30–45 m	45–60 m	45–60 m		
Width of stripe	4 m	6 m	6–10 m <sup>b</sup>	6–10 m <sup>b</sup>		
Lateral spacing between inner sides of stripes	6 m <sup>c</sup>	9 m <sup>c</sup>	18–22.5 m	18–22.5 m		







Aiming Point Marking Location			
Landing Distance Available Threshold to Beginnin (LDA)  Marking			
Less than 800 m	15 <mark>0 m</mark>		
800 m up to but not including 1200 m	250 m		
1200 m up to but not including 2400 m	300 m		
2400 m or more	400 m		





### 5.2.6 Touchdown zone marking

HOMAviation Training Center مرکز آموزش هـای هوایی همــــا

### **Application**

5.2.6.1 A touchdown zone marking shall be provided in the touchdown zone of a paved precision approach runway where the code number is 2, 3 or 4.

Landing distance available or the distance between thresholds	Pair(s) of markings
less than 900 m	1
900 m up to but not including 1 200 m	2
1 200 m up to but not including 1 500 m	3
1 500 m up to but not including 2 400 m	4
2 400 m or more	6

#### **Example:**

What shall be the length of touchdown zone if RWY length is

2355 m? 4x150=600

#### **Example:**

What shall be the length of touchdown zone if RWY length is 3050 m? 6x150=900


The pairs of markings shall be provided at longitudinal spacings of 150 m beginning from the threshold.



# Touchdown zone and aiming point marking 4 pairs



## Touchdown zone and aiming point marking 6 pairs















Figure 20.6 Pattern "A", basic plain markings

Figure 20.7 Pattern "B", distance coded



### 5.2.10 Runway-holding position marking

5.2.10.2 At an intersection of a taxiway and a non-instrument, non-precision approach or take-off runway, the runway holding position marking shall be as shown in Figure 5-6, pattern A.








### 5.2.10 Runway-holding position marking

5.2.10.3 Where a **single** runway-holding position is provided at an intersection of a taxiway and a precision approach **category I, II or III** runway, the runway-holding position marking shall be as shown in Figure 5-6, pattern **A**.

Where two or three runway-holding positions are provided at such an intersection, the runway-holding position marking closer (closest) to the runway shall be as shown in Figure 5-6, pattern A and the markings farther from the runway shall be as shown in Figure 5-6, pattern B.







### **Runway-holding position markings**

HOMAviation Training Center مرکز آموزش های هوایی هم

Note. — Patterns A1 and B1 are no longer valid after 2026.

#### PATTERN B1: PATTERN B2: PATTERN A1: PATTERN A2: 2 lines at 2 lines at 4 lines and 4 lines and 0.3 m each 0.3 m each 3 spaces at 3 spaces at 1 space at 0.6 m 1 space at 1.5 m 0.15 m each 0.3 m each

















Taxi-Holding Position


edge

Centreline











### Runway Holding Point Positions (Distance from Centre Line of Runway)

Type of Division	Runway code number				
Type of Runway	1	2	3	4	
Take-off	30 m	40 m	75 m	75 m	
Non-instrument (Visual)	30 m	40 m	75 m	75 m	
Non-precision Instrument	40 m	40 m	75 m	75 m	
Precision CAT I	60 m(b)	60 m(b)	90 m(a,b)	90 m(a,b,c)	
Precision CAT II/III			90 m(a,b)	90 m(a,b,c)	

#### **Notes:**

- a. May be increased if holding elevation lower than runway
- b. May be increased to avoid interference with radio navigation aids
- c. For code F this should be 107.5 m



### 1- Based on what criteria(s), the aerodrome reference code shall be determined?

- A) Wingspan.
- B) Outer main gear wheel span.
- C) Aeroplane reference field length.
- D) All answers are correct.


### 3- What shall be the minimum and maximum length of runway center line strip marking plus a gap in (m)?

- A) 50-60.
- B) 50-75.
- C) 60-80.
- D) 40-60.



### 1- Based on what criteria(s), the aeroc

- A) Wingspan.
- B) Outer main gear wheel span.
- C) Aeroplane reference field length.
- D) All answers are correct.



### 3- What shall be the minimum and maximum length of runway center line strip marking plus a gap in (m)?

- A) 50-60.
- B) 50-75.
- C) 60-80.
- D) 40-60.

The length of a stripe plus a gap shall be not less than 50 m or more than 75 m.



- 4- When the aiming point marking shall be provided at 400M from threshold, provided the RWY length is:
- A) 900 m.
- B) 2000 m.
- C) 3000 m.
- D) All answers are correct.

- 5- What shall be the length of touchdown zone if RWY length is 2355 m?
- A) 400 m.
- B) 500 m.
- C) 600 m.
- D) 700 m.



4- When the aiming point marking shall be provided at 400M from threshold, provided the RWY

length is:

A) 900 m.

B) 2000 m.

C) 3000 m.

D) All answers are correct.

Aiming Point Marking Location		
Landing Distance Available (LDA)	Threshold to Beginning of Marking	
Less than 800 m	150 m	
800 m up to but not including 1200 m	250 m	
1200 m up to but not including 2400 m	300 m	
2400 m or more	400 m	

### 5- What shall be the length of touchdown zone if RWY length is 2355 m?

A) 400 m.

B) 500 m.

C) 600 m.

D) 700 m.

Landing distance available or the distance between thresholds	Pair(s) of markings
less than 900 m	1
900 m up to but not including 1 200 m	2
1 200 m up to but not including 1 500 m	3
1 500 m up to but not including 2 400 m	4
2 400 m or more	6



### 14- When the aiming point marking shall be provided at 300 M from threshold, RWY Length is:

A) 4000 m

B) 3000 m

C) 1000 m

D) 2000 m

Aiming Point Marking Location			
Landing Distance Available (LDA)	Threshold to Beginning of Marking		
Less than 800 m	150 m		
800 m up to but not including 1200 m	250 m		
1200 m up to but not including 2400 m	300 m		
2400 m or more	400 m		

#### 15- What shall be the length of touchdown zone if RWY length is 3050 m?

A) 900 m

B) 800 m

C) 700 m

D) 600 m

Landing distance available or the distance between thresholds	Pair(s) of markings
less than 900 m	1
900 m up to but not including 1 200 m	2
1 200 m up to but not including 1 500 m	3
1 500 m up to but not including 2 400 m	4
2 400 m or more	6



### Simple approach lighting system

5.3.4.4 The lights forming the centre line shall be placed at longitudinal intervals of 60 m, except that, when it is desired to improve the guidance, an interval of 30 m may be used.

5.3.4.7 The lights of a simple approach lighting system shall be fixed lights and the colour of the lights shall be such as to ensure that the system is readily distinguishable from other aeronautical ground lights, and from extraneous lighting if present.

Each centre line light shall consist of either:

- a) a single source; or
- b) a barrette at least 3 m in length.






## Simple approach lighting system

#### Location

5.3.4.2 A simple approach lighting system shall consist of a row of lights on the extended centre line of the runway extending, whenever possible, over a distance of not less than 420 m from the threshold with a row of lights forming a crossbar 18 m or 30 m in length at a distance of 300 m from the threshold.











## Precision approach category I lighting system

5.3.4.10 A precision approach category I lighting system shall consist of a row of lights on the extended centre line of the runway extending, wherever possible, over a distance of 900 m from the runway threshold with a row of lights forming a crossbar 30 m in length at a distance of 300 m from the runway threshold.

### 5.3.4.19 Calvert System

If the centre line consists of lights, additional crossbars of lights to the crossbar provided at 300 m from the threshold shall be provided at 150 m, 450 m, 600 m and 750 m (i.e. 5 crossbars) from the threshold.







### Centerline lights





Precision approach category II and III


lighting system

5.3.4.22 The approach lighting system shall consist of a row of lights on the extended centre line of the runway, extending, wherever possible, over a distance of 900 m from the runway threshold.

In addition, the system shall have **two side rows of lights**, extending 270 m from the threshold, and two crossbars, one at 150 m and one at 300 m from the threshold.


5.3.4.23 The lights forming the centre line shall be placed at longitudinal intervals of 30 m with the innermost lights located 30 m from the threshold.


5.3.12.1 Runway centre line lights shall be provided on a precision approach runway category II or III.




MAviation Training Center

مرکز آموزش هـای هوایی هم





#### HOMAviation Training Center مرکز آموزش هـای هوایی همـــا





#### 7- What is the minimum length of simple approach lighting system?

A) 400 m.

B) 420 m.

C) 300 m.


D) 150 m.

#### Location

5.3.4.2 A simple approach lighting system shall consist of a row of lights on the extended centre line of the runway extending, whenever possible, over a distance of not less than 420 m from the threshold with a row of lights forming a crossbar 18 m or 30 m in length at a distance of 300 m from the threshold.

### 8- How many cross bar shall be provided for precision approach CAT I (single source)?

- A) 2
- B) 3
- c) 4
- D) 5






### 9- Which of the following RWY shall have center line lights?

- A) CAT I
- B) CAT II
- C) CAT III
- D) B and C are correct



- A) RWY length
- B) RWY width
- C) Both A and B are correct
- D) None



HOMAviation Training Center مرکز آموزش هـای هوایی همـــــا

Runway touchdown zone lights

5.3.13.1 Touchdown zone (TDZ) lights shall be provided in the touchdown zone of a precision approach runway category II or III.

5.3.13.2 Touchdown zone lights shall extend from the threshold for a longitudinal distance of 900 m.

on runways less than 1 800 m in length, the system shall be shortened so that it does not extend beyond the midpoint of the runway.

The lateral spacing between the innermost lights of a pair of barrettes shall be equal to the lateral spacing selected for the touchdown zone marking.

The longitudinal spacing between pairs of barrettes shall be either 30 m or 60 m.

5.3.13.3 A barrette shall be composed of at least three lights with a spacing between the lights of not more than 1.5 m.

5.3.13.5 Touchdown zone lights shall be fixed unidirectional lights showing variable white.










# Runway edge lights

- 5.3.9.1 Runway edge lights shall be provided for:
- a runway intended for use at night or
- for a precision approach runway intended for use by day or night.
- 5.3.9.3 Runway edge lights shall be placed along the **full length of the runway** and shall be in **two parallel rows** equidistant from the centre line.
- 5.3.9.4 Runway edge lights shall be placed along the edges of the area declared for use as the runway or outside the edges of the area at a distance of not more than 3 m.
- 5.3.9.6 The lights shall be uniformly spaced in rows at intervals of not more than 60 m for an instrument runway, an at intervals of not more than 100 m for a non-instrument runway.















# PAPI: Precision approach path indicator






# **VASIS**

# **PAPI**











# PAPI/VASIS

Precision approach path indicator Visual approach slope indicator










# 5.3.9 Runway edge lights

- 5.3.9.7 Runway edge lights shall be fixed lights showing variable white, except that:
- a) in the case of a displaced threshold, the lights between the beginning of the runway and the displaced threshold shall show red in the approach direction; and
- b) a section of the lights 600 m or one-third of the runway length, whichever is the less, at the remote end of the runway from the end at which the take-off run is started, may show yellow.






# 5.3.10 Runway threshold and wing bar lights

5.3.10.8 Wing bar lights shall be symmetrically disposed about the runway centre line at the threshold in two groups, i.e. wing bars.

Each wing bar shall be formed by at least **five lights** extending at least **10 m outward** from, and at right angles to, the line of the **runway edge lights**, with the innermost light of each wing bar in the line of the runway edge lights.

5.3.10.9 Runway threshold and wing bar lights shall be fixed unidirectional lights showing green in the direction of approach to the runway.



# 5.3.11 Runway end lights

5.3.11.1 Runway end lights shall be provided for a runway equipped with runway edge lights.

5.3.11.2 Runway end lights shall be placed on a line at right angles to the runway axis as near to the end of the runway as possible and, in any case, not more than 3 m outside the end.

5.3.11.4 Runway end lights shall be fixed unidirectional lights showing red in the direction of the runway.





# 5.3.12 Runway centre line lights

5.3.12.3 Runway centre line lights shall be provided on a runway intended to be used for take-off with an operating minimum below an RVR of the order of 400 m.

5.3.12.5 Runway centre line lights shall be located along the centre line of the runway, except that the lights may be **uniformly offset** to the same side of the runway centre line by **not more than 60 cm** where it is not practicable to locate them along the centre line. The lights shall be located from the threshold to the end at longitudinal **spacing of approximately 15 m**.







# 5.3.12 Runway centre line lights

### 5.3.12.7 Runway centre line lights shall be fixed lights showing:


- variable white from the threshold to the point 900 m from the runway end;
- alternate red and variable white from 900 m to 300 m from the runway end; and
- red from 300 m to the runway end,


except that for runways less than 1 800 m in length, the alternate red and variable white lights shall extend from the midpoint of the runway usable for landing to 300 m from the runway end.














# 5.3.18 Taxiway edge lights

5.3.18.1 Taxiway edge lights shall be provided at the edges of a runway turn pad, holding bay, de-icing/anti-icing facility, apron, etc., intended for use at night and on a taxiway not provided with taxiway centre line lights and intended for use at night.

5.3.18.7 **Taxiway edge lights** shall be **fixed lights** showing **blue**.








# 5.3.17 Taxiway centre line lights

5.3.17.6 Taxiway centre line lights on a taxiway shall be fixed lights showing green with beam dimensions such that the light is visible only from aeroplanes on or in the vicinity of the

taxiway.









# 5.3.17 Taxiway centre line lights

5.3.17.1 Taxiway centre line lights shall be provided on an exit taxiway, taxiway, de-icing/anti-icing facility and apron intended for use in runway visual range conditions less than a value of 350 m in such a manner as to provide continuous guidance between the runway centre line and aircraft stands, except that these lights need not be provided where the traffic density is light and taxiway edge lights and centre line marking provide adequate guidance.








### **LEGEND**

- Runway centre line light and runway edge light
- Taxiway edge light
- Taxiway centre line light
- Stop bar light
- Stop bar light (unidirectional)
  - Intermediate holding position light (unidirectional)





# 5.3.15 Rapid exit taxiway indicator lights




# Stop Bars and Lead-on Lights (CAP 637)

Lighted Stop Bars and Lead-on Lights are provided at those aerodromes authorised for low visibility operations.








AD 1.1-5 WEF 4 NOV 21


**AIP** ISLAMIC REPUBLIC OF IRAN

5. Low Visibility Procedures (LVP)










HOMAviation Training Center مرکز آموزش هـای هوایی هم





# 5.1.3 Signalling lamp


### **Application**

5.1.3.1 A signalling lamp **shall be provided** at a **controlled aerodrome** in the aerodrome control **tower**.

### **Characteristics**

- 5.1.3.2 Recommendation.— A signalling lamp should be capable of producing **red**, **green** and **white** signals, and of:
- a) being aimed manually at any target as required;
- b) giving a signal in any one colour followed by a signal in either of the two other colours; and
- c) transmitting a message in any one of the three colours by Morse Code up to a speed of at least four words per minute.





APPENDIX 4.
REQUIREMENTS
CONCERNING
DESIGN OF TAXIING
GUIDANCE SIGNS

red for mandatory instruction signs

B 25-07

LOCATION/RUNWAY DESIGNATION

B2
RUNWAY-HOLDING POSITION

A 25

25-07 B

25 CAT II

25 A





RIGHT SIDE



DIRECTION/LOCATION/DIRECTION



LOCATION/DIRECTION



LOCATION/RUNWAY VACATED









RUNWAY VACATED/LOCATION

**APRON** 

DESTINATION

**RUNWAY EXIT** 

**RUNWAY EXIT** 





DIRECTION/LOCATION/DIRECTION/DIRECTION




DIRECTION/DIRECTION/DIRECTION/LOCATION/DIRECTION/DIRECTION/DIRECTION



2500 m→

INTERSECTION TAKE-OFF



APPENDIX 4. REQUIREMENTS **CONCERNING DESIGN OF TAXIING GUIDANCE SIGNS** 

yellow for information, direction and destination signs



A 27 A	Indicates you are on taxiway "A", holding short of runway 27.
B 27-09	Indicates you are on taxiway "B" holding short at an intersection of runway 09-27. Where the threshold of runway 27 is on your left, and 09 on your right.
27 CAT II/III	Indicates the CAT II/III holding point for runway 27.
B2	Indicates a holding position protecting a priority route.
	No entry sign.











Indicating you are on Taxiway A

Indicating Taxiway B is the next right


Indicating Runway 27 is on the right

Indicating reciprocal Runways 27/09 are on the right

Indicating two different Runways 27 and 24 are on the right

Indicating the TORA from this intersection is 2500 m







## **Combination Signs**



Instrument holding point for Runway 27 at position A2



Intersection of taxiway A with taxiway B (A continues straight ahead)



Runway vacated on taxiway A (on the other side of this sign would be the holding point sign)



Taxiway entrance and holding point to two runways



LEFT SIDE

B 25-07

LOCATION/RUNWAY DESIGNATION

**B2** 

**RUNWAY-HOLDING POSITION** 



LOCATION/RUNWAY DESIGNATION

RIGHT SIDE

25-07 **B** 

RUNWAY DESIGNATION/LOCATION

25 CAT II


RUNWAY DESIGNATION/ CATEGORY II HOLDING POSITION

25 A


RUNWAY DESIGNATION/LOCATION
















# 7.1 Closed runways and taxiways, or parts thereof

7.1.1 A closed marking shall be displayed on a runway or taxiway or portion thereof which is permanently closed to the use of all aircraft.








# 7.1 Closed runways and taxiways, or parts thereof

7.1.1 A closed marking shall be displayed on a runway or taxiway or portion thereof which is permanently closed to the use of all aircraft.





### Signal **Description and Meaning** A horizontal white or orange 'T'. Takeoffs and landings are in the direction of the shaft of the 'T' as indicated by the arrow. A horizontal white dumb-bell. Aircraft must land, take off and taxi on runways and taxiways only. A horizontal white dumb-bell with black stripes. Takeoffs and landings are to be on a runway, but other movement on the ground is not confined to runways and taxiways.





A horizontal right-hand arrow of conspicuous colour. This may also be displayed at the end of the runway, or strip, in use.

A right-hand circuit is in force.

The letter 'C' in black against a yellow background.

The location of the air traffic services reporting office.

It is where pilots visiting an aerodrome should report.

A set of two digits, displayed vertically at or near the control tower for aircraft on the manoeuvring area.

The direction for takeoff, expressed in units of 10° magnetic to the nearest 10°.

period.

must

A horizontal white double cross. Sailplane (glider) flying is in progress.





07

The letter 'C' in black against a yellow background.

The location of the air traffic services reporting office.

It is where pilots visiting an aerodrome should report.

A set of two digits, displayed vertically at or near the control tower for aircraft on the manoeuvring area.

The direction for takeoff, expressed in units of 10° magnetic to the nearest 10°.



#### 6.2.2 Mobile objects

- 6.2.2.1 All mobile objects to be marked shall be coloured or display flags.
- 6.2.2.2 When mobile objects are marked by colour, a single conspicuous colour, preferably red or yellowish green for emergency vehicles and yellow for service vehicles, should be used.





#### Aerodrome traffic density.



Runway surface condition(s). A description of the condition(s) of the runway surface used in the runway condition report which establishes the basis for the determination of the runway condition code for aeroplane performance purposes.

- a) Dry runway. A runway is considered dry if its surface is free of visible moisture and not contaminated within the area intended to be used.
- b) Wet runway. The runway surface is covered by any visible dampness or water up to and including 3 mm deep within the intended area of use.
- c) Slippery wet runway. A wet runway where the surface friction characteristics of a significant portion of the runway have been determined to be degraded.
- d) <u>Contaminated</u> <u>runway</u>. A runway is contaminated when a significant portion of the runway surface area (whether in isolated areas or not) within the length and width being used is covered by one or more of the substances listed in the <u>runway surface condition</u> <u>descriptors</u>.



	Aircraft performance calculation Situational awareness			
Nature of Information	Mandatory	Optional		
Content	<ul> <li>i. Aerodrome location indicator;</li> <li>ii. Date and time of assessment;</li> <li>iii. Lower runway designation number;</li> <li>iv. RWYCC for each runway third;</li> <li>v. Percent coverage contaminant for each runway third;</li> <li>vi. Depth of loose contaminant for each runway third;</li> <li>vii. Condition description for each runway third; and</li> <li>viii. Width of runway to which the RWYCCs apply if less than published width.</li> </ul>	<ul> <li>i. Reduced runway length;</li> <li>ii. Drifting snow on the runway;</li> <li>iii. Loose sand on the runway;</li> <li>iv. Chemical treatment on the runway;</li> <li>v. Snowbanks on the runway;</li> <li>vi. Snowbanks on the taxiway;</li> <li>vii. Snowbanks adjacent to the runway;</li> <li>viii. Taxiway conditions;</li> <li>ix. Apron conditions;</li> <li>x. State-approved, and published use of, measured friction coefficient; and</li> <li>xi. Plain language remarks.</li> </ul>		
Example	ESSA 02170055 09L 3/3/3 100/100/100 06/06/06 WET SNOW/WET SNOW/WET SNOW	RWY09R ADI SNOWBANKS IWY B POOR		
Use	For calculating Aircraft Performance.	Planning flights and preparing for departure, approach, and taxi operations.		



### Runway Condition Assessment Matrix (RCAM)

Runway condition assessment matrix (RCAM)				
	Assessment criteria	Downgrade assessment criteria		
Runway condition code	Runway surface description	Aeroplane deceleration or directional runway control observation braking action		
6	• DRY			
5	<ul> <li>FROST</li> <li>WET (The runway surface is covered by any visible dampness or water up to and including 3 mm depth)</li> <li>Up to and including 3 mm depth:</li> <li>SLUSH</li> <li>DRY SNOW</li> <li>WET SNOW</li> </ul>	Braking deceleration is normal for the wheel braking effort applied AND directional control is normal.	GOOD	
4	<ul><li>−15°C and Lower outside air temperature:</li><li>COMPACTED SNOW</li></ul>	Braking deceleration OR directional control is between Good and Medium.	GOOD TO MEDIUM	



### Runway Condition Assessment Matrix (RCAM)

3	WET ("slippery wet" runway)  DRY SNOW or WET SNOW (any depth) ON TOP OF COMPACTED SNOW  More than 3 mm depth:  DRY SNOW  WET SNOW  Higher than -15°C outside air temperature¹:  COMPACTED SNOW	Braking deceleration is noticeably reduced for the wheel braking effort applied OR directional control is noticeably reduced.	MEDIUM
2	More than 3 mm depth of water or slush:  • STANDING WATER  • SLUSH	Braking deceleration OR directional control is between Medium and Poor.	MEDIUM TO POOR
1	• ICE <sup>2</sup>	Braking deceleration is significantly reduced for the wheel braking effort applied OR directional control is significantly reduced.	POOR
0	WET ICE 2  WATER ON TOP OF COMPACTED SNOW 2  DRY SNOW or WET SNOW ON TOP OF ICE 2	Braking deceleration is minimal to non- existent for the wheel braking effort applied OR directional control is uncertain.	LESS THAN POOR



- e) Runway surface condition <u>descriptors</u>. One of the following elements on the surface of the runway:
- i) Compacted snow. Snow that has been compacted into a solid mass such that aeroplane tires, at operating pressures and loadings, will run on the surface without significant further compaction or rutting of the surface.





- e) Runway surface condition descriptors. One of the following elements on the surface of the runway:
- ii) Dry snow. Snow from which a snowball cannot readily be made.





- e) Runway surface condition descriptors. One of the following elements on the surface of the runway:
- iii) Frost . Frost consists of ice crystals formed from airborne moisture on a surface whose temperature is below freezing. Frost differs from ice in that the frost crystals grow independently and therefore have a more granular texture.



e) Runway surface condition descriptors. One of the following elements on the surface of the runway:

• iv) Ice. Water that has frozen or compacted snow that has transitioned into ice, in cold and

dry conditions.





# e) Runway surface condition descriptors. One of the following elements on the surface of the runway:

 v) Slush. Snow that is so watersaturated that water will drain from it when a handful is picked up or will splatter if stepped on forcefully.





- e) Runway surface condition descriptors. One of the following elements on the surface of the runway:
- vi) Standing water. Water of depth greater than 3 mm.

Note.— Running water of depth greater than 3 mm is reported as standing water by convention.





- e) Runway surface condition descriptors. One of the following elements on the surface of the runway:
- vii) Wet ice. Ice with water on top of it or ice that is melting.





#### e) Runway surface condition descriptors.

One of the following elements on the surface of the runway:

 viii) Wet snow. Snow that contains enough water content to be able to make a well-compacted, solid snowball, but water will not squeeze out.






#### Runway condition code (RWYCC) for each runway third

Doc 9981

The codes are reported in a three-character group separated by a "/" for each third.



Runway condition code (RWYCC)
6
5
4
3
2
1
0
198



## Width of Runways

Width of Runways						
Code number	Code letter					
	Α	В	С	D	E	F
1(a)	18 m	18 m	23 m	-	-	-
2(a)	23 m	23 m	30 m	-	-	-
3	30 m	30 m	30 m	45 m	-	-
4	-	-	45 m	45 m	45 m	60 m
Note:(a): For a precision runway, w = 30 m where code is 1 and 2						



#### 3.4 Runway strips

3.4.1 A runway and any associated stop ways shall be included in a strip.

#### Length of runway strips

- 3.4.2 A strip shall extend before the threshold and beyond the end of the runway or stopway for a distance of at least:
- 60 m where the code number is 2, 3 or 4;
- 60 m where the code number is 1 and the runway is an instrument one; and
- 30 m where the code number is 1 and the runway is a non-instrument one.

#### Width of runway strips

- 3.4.3 A strip including a precision approach runway shall, wherever practicable, extend laterally to a distance of at least:
- **140** m where the code number is 3 or 4; and
- **70 m** where the code number is 1 or 2;

on each side of the centre line of the runway and its extended centre line throughout the length of the strip.




#### Width of Runway Strip

AIR LAW
ATPL GROUND TRAINING SERIES

A runway strip, wherever practicable, is to extend laterally on each side of the centre line of the runway and its extended centre line, throughout the length of the runway strip, to a distance defined in the table below.

Width of Runway Strip					
Type of Dunway	Runway code num <mark>be</mark> r				
Type of Runway	1	2	3	4	
Precision	75 m	75 m	150 m	150 m	
Non-precision	75 m	75 m	150 m	150 m	
Non-instrument	30 m	40 m	75 m	75 m	







#### 3.5 Runway end safety areas

- 3.5.1 A RESA shall be provided at each end of a runway strip where:
- the code number is 3 or 4; and
- the code number is 1 or 2 and the runway is an instrument one.
- 3.5.3 A RESA shall extend from the end of a runway strip to a distance of at least 90 m where:
- the code number is 3 or 4 (RECOMMENDED 240M); and
- the code number is 1 or 2 and the runway is an instrument one (RECOMMENDED 120M)
- 3.5.5 The width of a runway end safety area shall be at least twice that of the associated runway.



#### **OBSTACLES TO BE MADE FRANGIBLE**

The following areas must be maintained free of all but frangible equipment and installations required for air navigation:


- a) that portion of the runway strip within:
  - 1) 75 m of the runway centre line where the code number is 3 or 4; or
  - 2) 45 m of the runway centre line where the code number is 1 or 2;
- b) RESA;
- c) clearway;
- d) taxiway strip; and
- e) the area within 240 m of the end of the strip and within:
  - 1) 60 m of the extended centre line where the code number is 3 or 4; or
  - 2) 45 m of the extended centre line where the code number is 1 or 2 of a precision approach runway Category I, II or III.



#### 3.11 Taxiway strips

**Definition.** An area including a taxiway intended to protect an aircraft operating on the taxiway and to reduce the risk of damage to an aircraft accidentally running off the taxiway.

3.11.1 A taxiway, other than an aircraft stand taxilane, **shall** be included in a strip.



#### HOMAviation Training Center مرکز آمر\_\_\_\_\_\_

Taxiway, other than aircraft stand taxilane, centre line to object (metres)

Code

letter

#### Width of taxiway strips

VVIGUII OI	turi vay st	P
(1)	(11)	
A	15.5	
В	20	
C	26	
D	37	
E	43.5	
F	51	



#### 19.51 Width of Taxiways.


The straight portion of a taxiway should have a width of not less than that specified in the table below.

Taxiway Width				
Code Letter				
Α	7.5 m			
В	10.5 m			
С	15 m if the taxiway is intended to be used by aeroplanes with a wheel base less than 18 m; otherwise 18 m			
D	18 m if the taxiway is intended to be used by aeroplanes with an outer main gear span of less than 9 m; otherwise 23 m			
E	23 m			
F	25 m			

### AIR LAW ATPL GROUND TRAINING SERIES



### Transverse stripes (Doc. 9157 part 4)



- 2.2.1 Aprons and taxiways may be provided with shoulder stabilization, which has the appearance of pavement but which is not intended to support aircraft. Similarly, small areas within the apron area may have non-load bearing pavement that appears to be full strength.
- 2.2.2 The additional provision of transverse stripes on the non-load bearing surface has been found to be of assistance.
- 2.2.3 The transverse stripes should be placed perpendicular to the side stripe marking. The colour of the transverse stripes should be the same as that of the edge stripes, i.e. yellow.





#### Aerodrome traffic density.

a) Light. Where the number of movements in the *mean* busy hour is not greater than 15 per runway or typically less than 20 total aerodrome movements.



b) Medium. Where the number of movements in the mean busy hour is of the order of 16 to 25 per runway or typically between 20 to 35 total aerodrome movements.



c) Heavy. Where the number of movements in the mean busy hour is of the order of 26 or more per runway or typically more than 35 total aerodrome movements.





Note 1.— The number of movements in the *mean busy hour* is the arithmetic mean over the **year** of the number of movements in the **daily busiest hour**.

Note 2.— Either a take-off or a landing constitutes a movement.



# Simultaneous Operations

3.1.11 Recommendation.— Where <u>parallel non-instrument</u> runways are intended for <u>simultaneous</u> use, the minimum

- distance between their centre lines **should** be:
- — 210 m where the higher code number is 3 or 4;
- — 150 m where the higher code number is 2; and
- -120 m where the higher code number is 1.
- 3.1.12 **Recommendation.** Where <u>parallel instrument</u> runways are intended for <u>simultaneous</u> use, the minimum distance between their centre lines **should** be:
- 1 035 m for independent parallel approaches;
- 915 m for dependent parallel approaches;
- 760 m for independent parallel departures;
- — **760** m for **segregated** parallel operations;



#### 3.3 Runway turn pads

3.3.1 Where the end of a runway is not served by a taxiway or a taxiway turnaround and where the code letter is D, E or F [Wingspan>36m], a runway turn pad shall be provided to facilitate a 180-degree turn of aeroplanes.







Near-parallel runways. Non-intersecting runways whose extended centre lines have an angle of convergence/divergence of 15 degrees or less.





# Simultaneous Operations

- Dependent parallel approaches. Simultaneous approaches to parallel or near-parallel instrument runways where radar separation minima between aircraft on adjacent extended runway centre lines are prescribed.
- Independent parallel approaches. Simultaneous approaches to parallel or near-parallel instrument runways where radar separation minima between aircraft on adjacent extended runway centre lines are not prescribed.
- Independent parallel departures. Simultaneous departures from parallel or near-parallel instrument runways.
- Segregated parallel operations. Simultaneous operations on parallel or near-parallel instrument runways in which one runway is used exclusively for approaches and the other runway is used exclusively for departures.

